



Cosy display

Quick reference guide





About your Cosy display

The Cosy display shows the current temperature at its location. The light tells you which mode the heating is currently in. If you have more than one display, then the zone name is shown at the top of the screen.

Press the mode button once to view the temperature for the mode, then press it again to confirm. The light next to the mode button confirms that the heating mode is now active.

Comfy mode

Press the button to view the Comfy temperature and press again for one hour of Comfy.

Slumber mode

Press the **zZz** button to view the Slumber temperature and press again to set the system to Slumber and cancel the current mode.

Lower button

Press the **O** button to enable or disable the Cosy system (Hibernate mode) or to enable heating the hot water for one hour.



Cosy mode

Press the button to view the Cosy temperature and press again for one hour of Cosy.

Status lights

The lights next to each of the four buttons indicate the current mode of your Cosy system. A green light means that the system is at the desired temperature; a magenta light indicates that the system is heating; a blue light means the system is switched off

FAOs

Where is the best place for my Cosy display?

The display should be located away from radiators and out of direct sunlight.

My Cosy display is showing a link error

Move your display closer to the Cosy hub and make sure the hub is powered on.

The Cosy display is blank

When you have your Cosy display off the charging dock it will automatically reduce the display brightness to conserve power. Simply press any button and the display will come back on.

If the battery has no charge left, place the display back on the charging dock.

Get more help and support online http://comehometocosy.com/support